


**COMPONENTS**

<p><b>Handle POLO</b></p> <p>textile door stop, inserted 14 mm x 4 mm</p> <p>Length: 2,5 m, 2,7 m</p>	<p><b>Top track Blue</b></p> <p>75 mm</p> <p>Length: 1,5 m, 2,0 m, 2,5 m, 3,0 m, 4,0 m, 6,0 m</p>	<p><b>Bottom track Blue-V</b></p> <p>Option 1</p> <p>48 mm</p> <p>Length: 1,5 m, 2,0 m, 2,5 m, 3,0 m, 4,0 m, 6,0 m</p>	<p><b>Bottom track Blue-C</b></p> <p>Option 2</p> <p>42 mm</p> <p>Length: 1,5 m, 2,0 m, 2,5 m, 3,0 m, 4,0 m, 6,0 m</p>	<p><b>Rubber finishing profile for bottom track</b></p> <p>Length: 50,0 m</p>	<p><b>Gasket 4 mm</b></p> <p>4 mm</p> <p>10 mm</p>	<p><b>Gasket 4.5 mm</b></p> <p>4.5 mm</p> <p>10 mm</p>
<p><b>Top horizontal profile/ SIMPLE 10 mid-rail</b></p> <p>Length: 1,5 m, 2,0 m, 2,5 m, 3,0 m</p>	<p><b>Bottom horizontal profile Simple 10</b></p> <p>Length: 1,5 m, 2,0 m, 2,5 m, 3,0 m</p>	<p><b>Guiding carriage Blue 10 symetrical</b></p> <p>(Set)</p>	<p><b>Bottom carriage Simple/Blue 10V</b></p> <p>Option 1</p> <p>(Set)</p>	<p><b>Bottom carriage Simple/Blue 10C</b></p> <p>Option 2</p> <p>(Set)</p>	<p><b>Self-tapping screw Ø6.3x32</b></p>	

Dimensions of opening





handle length = door height

**door filling** - # 10 mm board, # 4 mm mirror or # 4.5 mm safety glass


door height	- h	$h = H - 35 \text{ mm}$
- without soft-close		$h = H - 35 \text{ mm}$
- with soft-close Simple MINI (bottom carriage <b>Blue 10V</b> )		$h = H - 39 \text{ mm}$
- with soft-close Simple MINI (bottom carriage <b>Blue 10C</b> )		$h = H - 42 \text{ mm}$
board height	- hb	$hb = h - 65 \text{ mm}$
door width	- w	$w = (W - 3 \text{ mm} + Z) : N$
board width	- wb	$wb = w - 18 \text{ mm}$
horizontal profile length	- L	$L = U = w - 34.2 \text{ mm}$
upper horizontal profile length - U		
mirror height	- hm	$hm = hb$
mirror width	- wm	$wm = wb - 4 \text{ mm}$

number of doors	- N	2	3
total overlap	- Z	18 mm	37 mm



visual design – 4 wings	
	$w = (W + 55) : 4$
	$w = (W : 2 + 15) : 2$




Dimensions helpful during installation of horizontal mid-rails in Simple 10 Frame systems



Installation method for fitting 10 mm board (diag. A) and 4 mm mirror or glass (diag. B)



Expansion gap taken into account when calculating the height of chipboard



**ATTENTION!**

Mirror (4mm) should be used with a safety backing film. Safety glass (4.5mm) comprises of two thin layers with a film in-between. Both mirror and glass need fitting gasket.