









COMPONENTS

<p>Handle Focus</p> <p>textile door stop (self-adhesive) 4.8 mm x 4 mm</p>  <p>#16 & #18</p>	<p>Top track Simple</p>  <p>68 mm</p>	<p>Bottom track Simple</p>  <p>44 mm</p>	<p>Rubber finishing profile for bottom track</p> 	<p>Angle section Mini</p>  <p>11 mm x 17 mm</p>	<p>Guiding carriage Simple 18 Board asymmetrical</p>  <p>(Set)</p>	<p>Bottom carriage Simple 18V Board</p>  <p>(Set)</p>
<p>Length: 2.4 m, 2.7 m</p>	<p>Length: 1.5 m, 2.0 m, 2.5 m, 3.0 m, 4.0 m, 6.0 m</p>	<p>Length: 1.5 m, 2.0 m, 2.5 m, 3.0 m, 4.0 m, 6.0 m</p>	<p>Length: 2.0 m, 3.0 m, 6.0 m, 50.0 m</p>	<p>Length: 1.7 m, 2.35 m, 3.0 m</p>		

Dimensions of opening




handle length = door height

door filling – #16 mm or #18 mm board

door height	- h	$h = H - 36 \text{ mm}$
- without soft-close		
- with soft-close Simple MINI end Simple CENTRAL		$h = H - 42 \text{ mm}$
board height	- hb	$hb = h - 1 \text{ mm}$
door width	- w	$w = (W - 3 + Z) : N$
board width	- wb	$wb = w - 3 \text{ mm}$
angle section length	- la	$la = w - 58 \text{ mm}$


number of doors	- N	2	3
total overlap	- Z	29 mm	58 mm

visual design – 4 wings	
	$w = (W + 84) : 4$
	$w = (W : 2 + 26) : 2$




- When fitting handle profiles, do not use assembly adhesive

Installation method for handle and guiding carriage with # 16 mm or 18 mm board



Installation method for angle section 11 mm x 17 mm



WARNING

We do not bear any responsibility for deformation resulting from the application of improper quality of boards (improper storage, improper humidity)

ATTENTION!

Remove protective film from aluminium elements (handles, tracks, connectors, etc.) prior to cutting them to the desired size. Film removal will reveal quality issues (eg. scratches)